

1

2

3

4

5

6

7

8

9

10

11

12

13

14

15

16

Use only on small depressions, otherwise water will get sucked into engine. Use distilled water. Measurement is difference between levels. Print on 11x17 paper with "Page Scaling" set to "None". ©2006 Sherbourne News, LLC, Detroit, Michigan